Reccomended Spare/Replacement Parts for Your Machine

Customer Name	BTM Company
Job Number	FC-25-22009
Part Name	Hinge

Feeding Concepts Inc.
317.773.2040
Parts@feedingconcepts.com

Please send all request for quotes and purchase orders to parts@feedingconcepts.com. All credit card transactions must be done through our Quote Valet system

FCI Part Number	Description	Quantity on Machine Shipped	Notes
Drive Unit Parts			
E-0379	E Series Vibratory Coil for Drive Unit	2	
SP-18-38	3/8" Springs for 18" Drive Unit	10	
#24	Rubber Isolation Feet for Drive Unit	4	
Hopper Parts			
E-0185	E Series Vibratory Coil for Hopper Driver	1	
SP-HP-18	1/8" Springs for Hopper Driver	4	
#27	Rubber Isolation Feet for Hopper Driver	4	
Inline Parts			
E-0383	E Series Vibratory Coil for Inline Driver	1	
SP-IN-18	1/8" Springs for Inline Driver	4	
Controls and Sensors			
121-000-2060	Rodix FC-200 Feeder Cube for Bowl, Hopper, Inline	3	

FU-77TZ	Keyence Thru-Beam Sensor	1
FS-N41C	Keyence Main Unit Amplifier	1
OP73864	Keyence Cordset for Amplifier	1
Q4XTBLAF500Q8	Banner Q4X Series Sensor for Bowl Level	1
RKT4-225/5M	Lumberg Cordset for Q4X	1
Other		
M100-34-6	Machine Leveling Feet	4