Airjet Setup Instructions

Job Serial Number: FC-26-223457
Part Description: WDP 260028-1
Equipment: Bowl Feeding System

Overview

This bowl feeding system utilizes (2) airjets. You just need to adjust the main regulator for each part.

- **AJ1 is set to 2 on the indicator for the flow controls.**
- **AJ2 is set to 2 on the indicator for the flow controls.**

The bowl was run at 21% on the FC-200.

Please note that the flow control indicators have some play between each number. The adjustment knob may need to be turned multiple times before the indicator changes to the next number setting.

Also note that the bowl speed percentages may need adjusted slightly once the bowl is mounted down on the machine, as mounting conditions can affect final tuning and performance.
